



### Boost Override Button Installation Instructions

1. Red wire to 12 V switch power. (Power on 4 channel frequency box)
2. White wire to open analog input (UTV input harness AN7- Pin 5 on Aux input harness)
3. Run and mount button anywhere you would like.
4. Drill 1/2 inch hole where you would like to mount.

