


Programming your ProEFI ECU

To begin programming your ProEFI ECU, follow these steps.

- Make sure the latest user software is installed on your pc.
- Before opening the software, make sure the CAN communications cable is plugged in to the USB port on your PC.
- Open the ProEFI Software
- Turn the ignition key to the on position (do not start the engine!)
- Select the 'Flash ECU' Icon as shown below




- Then select the file you wish to program into the ECU as noted at the top of the window that pops up.




- The ECU will then start it's programming procedure. The first step is to load the softboot, erasing any data currently on the ecu as shown below.



-
- Then the firmware application (with calibration) will be loaded as noted below.



-
- When the programming procedure is complete turn the ignition key off for 60 seconds allowing the ecu to fully reboot. Applications using a stepper motor may require to ignition cycles to properly park the Idle stepper motor.



-
- You are now ready to start using the new program!